

# KiSS PC-Link for Windows

## Introduction

KiSS PC-Link is a sharing application. It shares the audio, video and picture files located on your PC with your Linksys KiSS Media Player. All you need to do is to add the files you would like to share into the application's main window. To share content between your PC and your Linksys KiSS Media Player, you must make sure that both devices are connected on your home network (via Ethernet or wirelessly). To learn more about how to connect your Media Player onto your home network, please refer to your User Guide.

## Requirements

Windows PC computer running at least Windows XP, LAN Home Network, router recommended

## Installation

Just load the KiSS PC-Link CD in your PC. View the CD content, locate the "Windows" folder and open it. Double click the "KiSS PC-Link.exe" file to run the installer wizard. Follow the steps to finish the installation. When the installer has finished, you may start using KiSS PC-Link.

## Using KiSS PC-Link



The first time you will open the software you will be prompted to specify your TV Format and TV System. This will help displaying your pictures as good as possible on your television. If you do not want to answer yet, you can always go back to the KiSS PC-Link Settings menu, under File/Settings/Pictures

### Sharing content

First you need to select what type of file you want to share: Video, Audio or Picture files. Select the tab by clicking "Video", "Audio" or "Pictures" from the top of the main KiSS PC-Link window. There are three different ways of adding content, each way correspond to a button at the bottom of the main KiSS PC-Link window:

**Add Files:** Click this button to select the files you would like to share with your media player.

**New Folder:** Click this button if you would like to create a folder within your KiSS PC-Link main window. Once the folder will be created you will be able to add files within that specific folder

**Add Live Folder:** Click this button to link an existing folder, located anywhere on your computer, to KiSS PC-Link. All the files added to this folder on a later stage will automatically be updated with the KiSS PC-Link main window.

The "Remove" button removes the linked files from the KiSS PC-Link list, but doesn't delete them from your computer.

### Settings

Selecting File/Settings open a new window where you have access to different settings you might want to edit.

By default the "Pictures" tab is selected and gives you access to:

**Color Correction:** Click this button to let your computer calibrate the pictures itself for a better experience

**Scaling:** Click this button to let your computer scale your picture for better viewing on your television

**Compensate for non square pixels:** Click this button to let your computer enhance your picture for a better rendering

**TV Format and TV System:** Select your television Format and System

Click the Server tab to access:

**Server name:** Write the server name as it will appear on your television when you will access your shared files

Click the Extension tab to access:

**File extensions:** Edit the list of files your media player can view or play.

## Accessing the files on your television

If your network has correctly been set between your media player and your computer, you will be able to access the files without any problem. Make sure your media player is turned on and your television is on the video channel. Just press the "Menu" button from your remote control, scroll down to go to the "Media Server" tab. Select the type of file(s) you wish to access between Audio, Video or Pictures. The name of your PC-Link server will appear on your TV screen, select it to access and play the files you have added on your computer.